



# Fuelequip.com

3026 NW 72nd AVE • MIAMI, FLORIDA 33122

Tel (305) 477 - 5090

Fax (305) 471 - 0773

E-mail: [sales@fuelequip.com](mailto:sales@fuelequip.com)

E-mail: [joe@apsaviation.com](mailto:joe@apsaviation.com)

Web: <http://www.fuelequip.com/>

## FUEL SAMPLING EQUIPMENT



### FUEL SAMPLING EQUIPMENT

- The kits pictured here have become standard in the industry for obtaining test samples of jet fuel. With more than 40,000 in service, they have proved to pay for themselves by saving countless hours of downtime - because accurate contamination test results are obtained the first time.
- In the past, thousands of man hours have been wasted and fueling facilities have been shut down simply because the sampling tap was contributing dirt during the sampling period. Rusty pipe threads, steel gate valves and collections of reducing bushings that never are subjected to fuel flow, except when a contamination test is to be run, have been found to be a prime cause of poor color results when tests are performed to ASTM D2276. Flushing does not clean normally stagnant steel fittings.
- The probe penetrates through the pipe coupling that is welded to the pipe. There is no possibility of rust and dirt, that usually collects in stagnant sockets (such as welded couplings), reaching the test membrane.
- Non ferrous materials are used in our kits. All passages are small (1/4" pipe size) to insure that there will be enough velocity during the flushing cycle to carry away any sediment that may have collected.
- Kit No. 7T allows pressure testing and sampling independently through one pipe connection. Probe penetrates at the side through the tee. Sample never contacts the tap. Band or tee is for pressure (gas connection). It senses pressure on the outside of probe tube.

The GTP-144 Probe is made to reach the center of a 4" pipe but can be used in any pipe of 2" size up. The threads on the probe are both 1/2" NPT male. (Use reducing bushing to come down to this size.) We can also supply special probes (square or angle cut) of any specified length.











<p><b>BALL VALVES</b> Stainless Steel</p>  <p>GTP-1149-4F 1/4" Female GTP-1149-4M 1/4" Male GTP-1149-4MF 1/4" Male x Female</p>	<p><b>QUICK DISCONNECT COUPLER</b></p>  <p>GTP-992-2FA 1/8" Female NPT Aluminum GTP-992-2FS 1/8" Female NPT Stainless Steel GTP-992-4FS 1/4" Female NPT Stainless Steel GTP-992-4FA 1/4" Female NPT Aluminum GTP-992-2MA 1/8" Male NPT Aluminum GTP-992-4MA 1/4" Male NPT Aluminum GTP-992-2MS 1/8" Male NPT Stainless Steel GTP-992-4MS 1/4" Male NPT Stainless Steel</p>	<p><b>ACTUATOR NIPPLES</b> Stainless Steel</p>  <p>GTP-722 1/4" Female NPT GTP-722-2 1/8" Female NPT</p> <hr/> <p>GTP-150 Dust Plug for quick disconnect coupler, AL.</p>  <p>GTP-1232 Dust Cap for actuator nipple, AL.</p>
------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------	------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------	------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------



GTP-144 Sampling Probe, 1/4" Male NPT, Stainless Steel, standard 2 1/4" long tube.  
GTP-144-X Same as above, indicate desired TUBE length at "X"

### STAINLESS STEEL PIPE FITTINGS

<p><b>ELBOW</b> E-2 1/8" NPT E-4 1/4" NPT E-6 3/8" NPT E-8 1/2" NPT E-12 3/4" NPT</p> 	<p><b>COUPLING</b> C-2 1/8" NPT C-4 1/4" NPT C-6 3/8" NPT C-8 1/2" NPT C-12 3/4" NPT</p> 	<p><b>REDUCING BUSHING</b> RB4-2 1/4 TO 1/8 RB6-4 3/8 TO 1/4 RB8-4 1/2 TO 1/4 RB12-4 3/4 TO 1/4 RB16-4 1 TO 1/4</p> 
<p><b>STREET ELBOW</b> SE-2 1/8" NPT SE-4 1/4" NPT SE-6 3/8" NPT SE-8 1/2" NPT SE-12 3/4" NPT</p> 	<p><b>HEX NIPPLE</b> HN-2 1/8" NPT HN-4 1/4" NPT HN-6 3/8" NPT HN-8 1/2" NPT HN-12 3/4" NPT</p> 	<p><b>REDUCING COUPLINGS</b> RC4-2 1/4 TO 1/8 RC6-4 3/8 TO 1/4 RC8-4 1/2 TO 1/4 RC12-4 3/4 TO 1/4 RC16-4 1 TO 1/4</p> 
<p><b>TEE</b> T-2 1/8" NPT T-4 1/4" NPT T-6 3/8" NPT T-8 1/2" NPT T-12 3/4" NPT</p> 	<p><b>NIPPLE, SHORT</b> SN-2 1/8" NPT SN-4 1/4" NPT SN-6 3/8" NPT SN-8 1/2" NPT</p> 	

### INSTRUCTIONS FOR SAMPLING PROBE KITS

**1. INSTALLATION** Screw the GTP-144 probe in a 1/4" NPT female thread using 1 1/2 wraps of Teflon pipe thread dope as a sealant and thread lube. Use reducing bushings if necessary.

**TIP:** Wrap the tape tightly, so that it forms itself into the male thread. Do not let the tape extend beyond the open end of the fitting or fragments of the tape will get into the flow stream. NEVER screw stainless steel threads together without Teflon dope - They will gall.

**A.** Adjust the position of the probe by tightening until the arrow on the flat of the hex is pointing downstream - in the direction of flow in the pipe.

**B.** Install other components of the kit using Teflon pipe thread dope for each connection. Be certain that sample flow is in the direction of the arrow shaped handle of the ball valve.

**C.** The sampling coupler is supplied with a dust plug having a ball chain for attachment. Place the ring on the ball chain over the threaded end of the coupler before assembling.

**2. FLUSHING** - A new sampling connection requires extensive flushing. For best results use the GTP-1110 Bonding and Grounding Hose (see Bull. 114) to obtain high velocity in the passages of the sampling kit components.

**3. CONTAMINATION TESTING** - Use Gammon MiniMonitor® Kit model GTP-172. Follow detailed instructions for best results.

**TIP:** The sampling coupler can be connected without the risk of spraying fuel, if this procedure is followed:

**A.** Slide the collar of the coupler all the way as far as it will go toward its threaded end. Remember that the collar does not open the internal valve.

**B.** Insert the connecting nipple in the open port of the coupler as far as it will go without depressing the internal valve, but continue to hold the collar.

**C.** Then quickly press the nipple straight in with a force of about 25 lbs. and pull the collar back to its original position. This 25 lb. force causes the internal valve to open.

**D.** A dry disconnection can be made simply by depressing the collar.